



- = CRITICAL SPARE PART
- = SUGGESTED SPARE PART
- △ = FASTENER INCLUDES HI COLLAR LOCKWASHER

ITEM	QTY	PART NUMBER	SP	DESCRIPTION
52	4	375-48		BRASS BUSHING, FLANGED
51	2	272-07	○	6-32x.375" SOC FLAT
50	1	272-06	●	WEAR PLATE
49	1	257-01	○	VERTICAL MEMBER
48	1	425-01		FJS INTERFACE BRACKET
47	1	375-24		BRACKET, INTERFACE

ITEM	QTY	PART NUMBER	SP	DESCRIPTION
46	4	374-46	△	5/16-18x1.25" HEX HEAD BOLT
45	2	374-45		BALL PLUNGER
44	4	374-44	△	1/4-20x1.0" SOC CAP
43	1	257-23		VERT SUPPORT PLATE, OFFSET
42	1	257-18		VERT SUPPORT PLATE, INLINE
41	1	363-19		TOGGLE SHOE
40	1	363-11	○	SPRING
39	1	257-06		SPRING BLOCK
38	1	257-07		PISTON SHAFT
37	1	363-21	○	STOP PIN
36	1	257-08	○	PISTON BLOCK
35	4	363-20	○	FLANGE BUSHING
34	2	363-16	○	5/16x1.25" SHOULDER BOLT
33	2	257-02		ARM, HORIZONTAL SUPPORT
32	1	374-32		ADJUSTABLE STOP W/ LOCKNUT
31	4	374-31	○	SPRING WASHER
30	2	374-30	○	THRUST WASHER
29	2	374-29	●	SNAP RING
28	2	375-28		RUBBER BOOT, HORIZ ROD
27	2	374-27	△	10-32x.50" THUMB SCREW
26	2	374-26		THRUST WASHER .020"
25	2	374-25		LOCK KNOB
24	1	374-28		RUBBER BOOT, ADJUSTING ROD
23	1	375-23		PLATE, HORIZONTAL SUPPORT
22	1	375-22		END PLATE, HORIZ ROD
21	1	375-21		END PLATE, HORIZ
20	2	375-20		SHAFT, HORIZONTAL SLIDE
19	2	X059		5/16-18x.75" SOC FLAT
18	2	374-18		10-32x.625" SOC FLAT SS
17	1	374-17		RETAINER, THREAD PLATE
16	1	375-16		COVER, ROD
15	4	374-15	△	1/4-20x1.0" HEX HEAD BOLT
14	2	374-14	△	3/8-16x1.5" SOC CAP
13	1	374-13		PIN, HINGE
12	3	374-12		1/4-20x.75" SOC FLAT
11	1	374-11		HINGE PLATE
10	1	374-10		BEARING PLATE, HINGE
9	1	374-09		ADJUSTMENT SCREW, HORIZ
8	1	374-08		THREAD PLATE, HORIZONTAL
7	2	X057	△	5/16-18x1.25" SOC CAP
6	6	374-06	△	5/16-18x1.0" SOC CAP
5	1	375-05		BLOCK, HORIZONTAL SLIDE
4	1	374-04		ADJUSTMENT SCREW, VERTICAL
3	2	375-03		SHAFT, VERTICAL SLIDE
2	1	375-02		THREAD PLATE, VERTICAL ROD
1	1	375-01		BLOCK, VERTICAL SLIDE

VALVE SLIDE ASSEMBLY



5 Harris Court, Unit O
 Monterey, CA 93940
 Tel: 831.642.6565
 Fax: 831.642.6563

NUMBER
 375
 REV
 B4